



## RALLY WINDSHIELD 660

1 – REMOVE THE ORIGINAL WINDSHIELD.

2 – FIX THE NEW SUPPORT IN THE ORIGINAL HIGH FASTENERS.



3 – FIT THE RALLY WINDSHIELD USING THE 4 ORIGINAL SCREWS USING THE RUBBER WASHERS.

